

MASTURBATOR PIPEDREAM PDX ELITE VIBRATING ROTO TEASER



User manual

CONTROL

- 1) Short press the button with the wave symbol to start the vibration and pulsation mode.
- 2) Repeated short presses change the individual rhythms.
- 3) To switch off, hold the button for 3 seconds.
- 4) Short press the + button to switch on the first rotation speed and shift the intensity.
- 5) Press the - button to decrease the speed until the rotation is switched off.
- 6) Short press the middle X button to change the direction of rotation.

MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The masturbator is water resistant, so maintenance is very easy.

Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!**

You could only immerse the product in water if it was **waterproof**.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The masturbator is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Masturbator and three erection rings.