

ANAL PLUG PIPEDREAM ANAL FANTASY INFLATABLE P-SPOT MASSAGER



User manual

CONTROL

- 1) Insert 2 AA batteries into the remote control according to the marked poles.
- 2) There is a rotary wheel on the remote control to turn the vibration on and off, but it is also used for smooth vibration settings.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **not waterproof or water resistant!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vibrator with remote control and balloon.