

VACUUM PUMP POWER VIBRATING

User manual



CONTROL

- 1) Insert 2 AA batteries into the remote control according to the marked poles.
- 2) Insert the hose leading from the pump into the balloon.
- 3) There is a wheel on the side of the remote that turns on the vibrating egg and then rotates it to control the intensity of the vibration.
- 4) Turn it completely off by turning it to the OFF position.
- 5) Squeezing the balloon will create a vacuum and suction sensation.

MAINTENANCE

After each use, rinse the pump with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The pump is **not water resistant or waterproof!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The controller is powered by two AA batteries. We recommend using alkaline batteries for greater endurance or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vacuum pump with remote control and balloon.