

# VIBRATOR VIBE THERAPY TRI

## User manual



### CONTROL

- 1) The bottom of the vibrator serves as a cover for the battery.
- 2) To turn on the vibrator, remove the battery cover, insert 3 AAA batteries (not included) and screw the cover back on.
- 3) To turn the vibrator on and off, press the "power" button.
- 4) Change the individual vibration rhythms by briefly pressing the button with the wave symbol.

### MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The vibrator is **water resistant**, so maintenance is very easy.

Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!**

You could only immerse the product in water if it was **waterproof**.

### LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The vibrator is powered by three AAA batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

Vibrator.