

# VIBRATING EGG SEVEN CREATIONS LUXURY POWER REMOTE BULLET



## User manual

### CONTROL

- 1) Press the button on the egg briefly to put it into standby mode. You will know this by its LED flashing.
- 2) Subsequent short button presses will turn on and change the vibration and pulsation modes.
- 3) To turn it off, long press and hold the button for 3 seconds.
- 4) To use the remote control, place the egg in standby mode and press the bottom power button on the remote.
- 5) This will turn on the vibration and switch modes using the top button with the wave symbol.
- 6) To pause the vibration, briefly press the power button again.
- 7) Turn the egg completely off again with the button by the handling loop.

### MAINTENANCE

After each use, rinse the egg with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The egg is **water resistant**, so maintenance is very easy. The egg can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case. The remote control is **not water resistant or waterproof!**

### LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The egg is powered by an integrated Li-ion battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. Charging time is about 90 minutes. The remote control is powered by CR 2032 battery.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

The package includes a vibrating egg, remote control, USB charging cable and a CR 2032 battery.