

# CRYSTAL CLEAR SET (VIBRATING EGG AND VIBRATOR)



## User manual

### EGG CONTROL

- 1) Insert 2 AA batteries into the remote control.
- 2) Start the egg by turning the wheel on the remote control to the right.
- 3) Use the wheel to control the vibration of the egg.

### VIBRATOR CONTROL

- 1) The bottom of the vibrator serves as a cover for the batteries.
- 2) Unscrew the cover and insert AA battery and screw the cover back on.
- 3) Start the vibrator by turning the wheel at the bottom of the cover.
- 4) Turn the same wheel to control the intensity of the vibration.

### MAINTENANCE

Rinse the tools with lukewarm water and soapy detergent after each use.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The tools **is not waterproof or water resistant!**

### LUBRICATION

For the vibrator and vibrating egg, use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The vibrator is powered by AA battery. The egg is powered by two AA batteries.

We recommend the use of alkaline or rechargeable batteries for greater endurance.

### STORAGE

Store separately from other erotic aids in a dry and dark place.