

SADA LOVE BOX INTERNATIONAL (Vibrator)



User manual

CONTROL

- 1) The bottom of the vibrator serves as a cover for the batteries.
- 2) First remove the battery cover, insert the AAA battery (included) according to the marked poles and screw the cover back on.
- 3) Turn on the vibrator by sliding the switch to the "ON" position on the battery cover.
- 4) Switch off by sliding the switch to the "OFF" position.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **not waterproof or water resistant!**

LUBRICATION

Due to the material of the product, you can use **lubricants of any base**.

DRIVE AND CHARGING

The product is powered by one AAA battery. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.