A&E VIBRATION BUMPY BEAD SET

User manual

CONTROL

AGRANT

- 1) Unscrew the cap and insert the battery according to the poles.
- 2) Screw on the cap and briefly press the button to start the first vibration.
- 3) Subsequent short presses change the individual vibration and pulsation modes.
- 4) To turn off the cartridge, hold the button for 3 seconds.

MAINTENANCE

After each use, rinse the anal plug with lukewarm water and soapy detergent. You can also use an erotic cleaner, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The anal plug is **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The cartridge is powered by an AAA battery. We recommend using an alkaline battery for greater durability or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

3 anal plugs and vibrating cartridge.



Trinet Corp., s.r.o.

Provozní 5560/1b 722 00 Ostrava – Třebovice, Czech Republic

Potřebujete poradit?

Napište nám na flagranti@flagranti.cz nebo zavolejte na tel.: +420 774 082 678