EasyToys Vivid Cock Ring black

USER MANUAL



CONTROL:

1. **Power on/off:** short press the “ON/OFF” button

MAINTENANCE:

ATTENTION! After each use, do not forget to thoroughly clean the device; this will extend its lifespan.

We also recommend using a sex toy cleaner, which also helps remove microscopic dirt. Simply spray the product on, leave it on for about 1 minute, and then dry with a lint-free towel or cloth.

WATER RESISTANCE:

Splash-proof (IPX5): fine around water, just don't submerge it.

LUBRICATION:

Use only WATER-BASED lubricants. Other lubricants (e.g. silicone) could irreversibly damage the surface of the device and make it sticky.

CHARGING:

The bullet runs on 3 LR41 batteries. Remove the bullet vibrator from the silicone ring before using it for the first time. Unscrew the cap and check the inside of the battery compartment for a small white circular piece of paper. This is a transport insulator and it will stop the bullet from working if you leave it in, so make sure it's removed before you put the cap back on.

STORAGE:

Store separately from other sex toys in a dry, cool and dark place out of the reach of children.

PACKAGE CONTENTS:

- 1× cock ring
- 3×LR41 batteries
- 1× user manual

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169