

2IN1 LIBO SCORPIO MASSAGE HEAD AND VIBRATOR



User manual

CONTROL

- 1) On/Off - using the two arrows. You can have both motors on at the same time, or just one of them.
 - 2) To switch on, just press one of the two arrows briefly.
 - 3) To switch off, this arrow must be held for a longer time.
 - 4) The vibrator can also be switched off by briefly pressing the arrow after clicking through all vibration and pulsation modes.
 - 5) Switching between modes - easy, just press the arrow again after switching the vibrator on, which changes the vibration program.
 - 6) The H button - or climax mode, is used to climax quickly - just press it just before just before the onset of orgasm.
 - 7) The vibrator will begin to vibrate intensely for approximately 20 seconds. It then switches itself to mode to the previous vibration type that the user had set.
- This function can be used for either of the two motors. Not for both at the same time.

MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent.
You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrator is **water resistant**, so maintenance is very easy.
The vibrator can be splashed with water, but you **MUST NOT immerse it in water!**
Waterproof means that you could completely submerge the product in water and enjoy water play.
Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrator and USB cable for charging.