

PUMP WITH VIBRATOR 2IN1 YEQU MARTHA

User manual



CONTROL

- 1) To draw in air, hold the top button with the dot symbol on the right for 3 seconds.
- 2) Short presses change the air intake intervals.
- 3) To quickly release the vacuum, hold down the third button with the dot symbol on the left.
- 4) The button with the lip symbol controls the movements of the tongue. Hold it to turn on or off for 3 seconds and short presses to change oral stimulation modes.
- 5) From the handle, turn the vibrator with the last bottom button with the vibration symbol.
- 6) Hold the button again for 3 seconds to start.
- 7) Additional short presses change the vibration and pulsation rhythms and turn off by holding the button for 3 seconds.
- 8) All modes work independently.

MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent.

You can also use an erotic cleaner, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrator is not waterproof or water resistant!

LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Trinet Corp., s.r.o.

In the package you will find a vibrator and magnetic USB cable for charging.

