


PRODUCT NAME BS1010
 SIZE 189*43*101.5MM
 MATERIAL ABS · SILICONE
 BATTERY CAPACITY 450mAh
 USAGE TIME 2H
 NOISE <45dB
 WATERPROOF IP67
 RECHARGE TIME 2H

1 VIBRATION MODE (3+8)

- NORMAL 1-3
- ENTHUSIASM MODE
- SHAKING MODE
- PLEASURE MODE
- PASSION MODE
- CLIMAX MODE



SUCKING MODES (5)



2 BUTTONS FUNCTION

- ON&OFF ----- LONG PRESS*
- M1 THREE SUCKING MODES ----- CLICK*
- M2 EIGHT VIBRATE MODES ----- CLICK*
- M1 M2 NOT WORKING AT THE SAME TIME

3 LIGHTS INDICATOR

- POWER ON ----- LIGHT ON
- WORKING ----- LIGHT ON CONTINUOUSLY
- POWER OFF ----- LIGHT OFF
- CHARGING ----- LIGHT BLINK
- FULLY CHARGED ----- LIGHT ON ALL TIME

USING SCENES



1 SUCKING NIPPLE



2 SUCKING CLITORIS



3 INSERT VAGINA


CLEANING AND MAINTENANCE



1. OPEN THE HEAD AND RINSE



2 DRY WITH A CLOTH AND ASSEMBLE



3 PLACE IN A CLEAN, DUSTPROOF AND COOL PLACE

WARNING!

APPROPRIATE MAINTANCE AND TAKING-CARE COULD EXTEND USAGE OF THE PRODUCT. PLEASE READ THE SECURITY DESCRIPTION BEFORE USING THE PRODUCT

1. FOLLOW THE STEPS BELOW BEFORE USING THE PRODUCT

- CLEAN AND DISINFECTION IS NECESSARY BFORE USE. USE ANTIBACTERIAL SOAP OR CLEANING LIQUIDS WITH WARM WATER, DRY IT WITH TOWEL OR SOFT CLOTH

2. DURING USING

- MASSAGE OIL OR HAND CREAM IS FORBIDDEN TO USE WITH THE PRODUCT
- SILICONE SUBSTRATE LUBRICANT IS FORBIDDEN TO USE WITH THE PRODUCT. IT WILL HURT SILICONE SURFACE

SAFETY INFO!

- THIS PRODUCT MAY HAVE SMALL COMPONENTS THAT HARM CHILDREN'S HEALTH. PLEASE KEEP IT AWAY FROM CHILDREN. SWOLLOW BAG OR SMALL COMPONENTS CONTAINED MAY CAUSE CHOKE
- USERS CAN'T CHANGE OR MAINTAIN ANY COMPONENTS. EXCEPT AUTHORIZED DISTRIBUTOR OR MAINTAINANCE CENTER. IF ANY COMPONENTS OF YOUR PRODUCT NEED TO CHANGE IN ANY REASON. INCLUDE NORMAL ABRASION OR BREAKAGE. PLEASE CONTACT WITH YOUR LOCAL DISTRIBUTOR
- DONT USE IT IN ANY AREA (SUCH AS HOSPITAL & PLANE) THAT NEED TO SHUT DOWN ELECTRONIC EQUIPMENTS OR RADIO FREQUENCY REMOTE PRODUCTS

REMEMBER: DONT CLEAN IT WITH DETERGENT CONTAINED ALCOHOL, GAS OR ACETONE, AVOID DIRECT SUN OR EXPOSING HIGH TEMPRATURE ENVIRONMENT. THIS PRODUCT SHOULD BE KEPT IN CLEAN AND DRY PLACE, AND DO NOT PUT TOGETHER WITH OTHER PLASTIC PRODUCTS

BUILT-IN BATTERY MAINTENANCE

- BUILT-IN BATTERY MAINTENANCE. THE BATTERY INSIDE IS RECHARGEABLE AND IT CAN GET AGING AFTER RECHARGED FOR HUNDREDS OF TIMES. PLEASE TAKE OUT THE CHARGER AFTER FULLY CHARGED. OVER CHARGED MAY REDUCE THE USAGE LIFE OF THE BATTERY
- FULL CHARGED BATTERY WILL LOSE POWER SLOWLY EVEN YOU DONT USE IT
- TOO HOT OR COLD ENVIRONMENT CAN REDUCE THE VOLTAGE OF BATTERY AND ALSO THE USAGE. IF THE BATTERY IS TOO HOT OR TOO COLD, ITS USAGE TIME WILL DECREASE EVEN IF FULLY CHARGED

BATTERY WARNING

- CAUTION--- ANY WRONG OPERATION CASES WITH THE BATTERY MAY HAVE RISKS OF CAUSING FIRE OR CHEMICAL BURN. DAMAGED BATTERY HAVE RISK OF EXPLODING
- SUGGEST USE OUR ORIGINAL CHARGER TO CHARGE
- PLEASE HANDLE THE BATTERY ACCORDING TO LOCAL LAWS. IF POSSIBLE PLEASE USE RECYCLE. USERS CAN'T TAKE OUT OR CHANGE BATTERY BY THEMSELVES, SUCH KINDS OF BEHAVIOR MAY CAUSE HAZARD AND BREAK THE PRODUCT

CHARGE WARNING!

- DONT CHARGE WITH OTHER ADAPTOR, IT MAY BREAK THE VIBRATOR AND CAUSE HAZARD. AT THE SAME TIME, IT WILL LOSE MAINTAINANCE GUARANTEE

IMPORTANT:

PLEASE CHECK USER GUIDE TO CHECK LIGHTS INDICATORS, SOME VIBRATORS CAN'T USE DURING CHARGE.