

Please carefully read this Manual before using this Product for the very first time.

## User's Manual

### Joy Rock

Twist Massager

#### Notice of Cleaning

- ◆ Please clean your "toy" after use ASAP to keep out microorganism breeding since great amount of secreta and lubricating oil will be reserved on it.
- ◆ Please clean it with warm water and soap; it is recommended to clean it in association with the specific detergent of flirt toys, to implement disinfection by using disinfectant or 75%alcohol (alcohol is not recommended for long-use to avoid corroding surface of the "toy" and prevent it aging).
- ◆ Drying: it is recommended to wipe it with cotton or high-quality tissueafter cleaning. Please have it dried naturally and avoid excessive exposure to sunlight.
- ◆ Please keep it in dustless place and be away from articles of other materials.

#### Safety Notice


As a closest partner for masses of users, this Product should be used safely and healthily by all as the joint responsibility of users and us.

Prompts for masses of users:

- ◆ As a private article, this Product should not be shared for the sake of your health.

#### Specification & Parameters

Materials: Silica gel, ABS      Charging: Lithium battery  
 Duration: 1-2h      Waterproof grade: IPX-7  
 Size: 240mm (L) × 34mm (D)  
 Frequency conversion mode: 10-section variable frequency  
 Charging period: About 3h  
 Package: Twist massager, User's Manual, charging wire



- ① Major motor
- ② Twist massage end
- ③ Secondary motor
- ④ Major motor function key
- ⑤ Start/secondary motor function key
- ⑥ Twist function key
- ⑦ Magnet charging port

- ◆ This Product supports vibration at different frequencies to meet demands of various users. Please stop using it immediately if feeling uncomfortable or allergic.
- ◆ If using this Product for stimulating anus, please use it with much attention to avoid dropping it into your body which could bring in damages. It is recommended to be used with lubricating product together for better effects.
- ◆ If this Product has sharp and unsmooth head, please stop using it immediately.
- ◆ Please stop using it immediately if feeling uncomfortable in use.
- ◆ Please keep this Product and its parts inaccessible to children or pets to avoid accidental ingestion and if any ingestion occurs, please immediately go to hospital nearby.

#### After sales service

**A** Please save your receipt to insure that you can enjoy the after sales service.

Warranty period of this product is 12 months. If any quality problem during this period, please contact us to get our efficient and good quality service. We do not provide quality guarantee service if the damage is caused by the users.

#### About Product

As a novel and twist vibration rod which integrates the strong vibration as ordinary vibration rod and the unique twist function, Joy Rock can bring faster and fierce climax to women. The environmentally friendly silica gel can bring in comfortable feel of touch and you may choose different vibration frequencies as you like to enjoy it in and out.

#### Vibration Mode

1. 10-frequency vibration mode

#### Steps of Use

- ◆ Long press "Start" for 2s under off state to start it and enter standby state
- ◆ Short press "Start" to start motor, shot press it again to enter the next vibration mode, or keep pressing to have circular switch between 10 vibration modes.
- ◆ Short press vibration start key at head to start head motor, shot press it again to enter the next vibration mode, or keep pressing it to have circular switch between 10 vibration modes.
- ◆ Short press twist start key to enable twist functions at low gear, short press it to have stepless speed regulation and switch gear.
- ◆ Long press "Start" for 2s under startup state to turn off.



Green materials



Low noise



Ergonomic design



Portable



Enough power, durable service



IPX-7waterproof



Ideal gift