

VIBRATOR ANNE'S DESIRE RABBIT WIRELESS TECHNOLOGY WATCHME



User manual

CONTROL

- 1) Hold the bottom power button on the vibrator for 3 seconds. It will greet you by lighting up the LED and going into standby mode.
- 2) Subsequent short presses of the top button with the ripple symbol will turn it on and move the vibration and pulsation one level forward.
- 3) Short presses of the bottom button move back one level.
- 4) Turn it off by long pressing the power button again for 3 seconds.
- 5) For use with the remote control, place the vibrator in standby mode.
- 6) Subsequently press the middle button on the watch with the wheel symbol for 3 seconds to switch on the remote control.
- 7) Short presses of this button switch on and change the different modes.
- 8) Short presses of the arrow buttons adjust the intensity of the vibration.
- 9) Hold the button with the wheel for 3 seconds to turn the vibrator off.

MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent. You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrator is **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play. The driver is only **water resistant**, so only splashing water can hit it.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. The watch (remote control) is also charged with a USB cable.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrator, watch (remote control) and 2x magnetic USB cable for charging.