

PENIS RING PRIMEROS VIBRATING



User manual

CONTROL

- 1) Briefly press the button on the tip of the ring to start the vibration.
- 2) Briefly press the button on the tip of the ring to turn off the vibration.

MAINTENANCE

After each use, remove the cartridge from the ring and rinse with lukewarm water and soap. You can also use a [sex toys cleaner](#), which additionally helps to remove microscopic dirt. Just spray the product, let it work for about 1 minute and then dry it with a lint-free towel or cloth.

WATER RESISTANCE

The vibrating ring is not waterproof or waterproof. Therefore, if you want to clean it, you always need to remove the vibrating cartridge!

LUBRICATION

Use only [WATER BASED lubricants](#). Other lubricating gels could damage the surface of the device and it would then become sticky.

PROPULSION AND CHARGING

The vibrating ring is powered by a single use battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGE CONTENTS

The package includes a vibrating ring.