RS ESSENTIALS KIT D'AMOUR (Vibrator)

User manual

CONTROL

AGRANT

1) The bottom of the vibrator serves as a cover for the batteries.

2) First remove the vibrator cover, turn the silver part to the "OPEN" position, insert the AA battery (not included) and screw it back on.

3) Turn the vibrator on by turning it to the "ON" position.

4) Turn the vibrator off by turning it to the "OFF" position.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is not waterproof or water resistant!

LUBRICATION

Due to the material of the product, you can use lubricants of any base.

DRIVE AND CHARGING

The product is powered by one AA battery. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

A vibrator, an eye mask, a feather teaser and a pouch for storing your toys.



Trinet Corp., s.r.o.

Provozní 5560/1b 722 00 Ostrava – Třebovice, Czech Republic

Potřebujete poradit?

Napište nám na flagranti@flagranti.cz nebo zavolejte na tel.: +420 774 082 678