

MIA ROSE STIMULATOR



CONTROL

- 1) Hold the button on the side of the bud for 3 seconds to turn on.
- 2) The teaser will greet you with an LED backlit button and start the first pulsation mode.
- 3) Subsequent short presses of the button change the individual rhythms
- 4) You turn it off by long pressing the power button again for 3 seconds.

MAINTENANCE

After each use, rinse the stimulator with lukewarm water and soapy detergent.

You can also use an erotic aid cleaner, which additionally helps to remove microscopic dirt.

Simply spray the product on, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The stimulator is waterproof, so its maintenance is very easy.

It may get splashed with water, but DO NOT submerge it in water!

LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and the lubricant will become sticky.

DRIVE AND CHARGING

The stimulator is powered by a high quality integrated Li-on battery, which is approximately one half charged from the factory, but we recommend that you fully charge it before first use.

Charging of the battery should be done using the included USB cable, which can be plugged into the adapter on the phone, PC or power bank.

When charging, the LED flashes and when fully charged, the LED indicator lights permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find the stimulator and a magnetic USB cable for charging.