

Masturbator VIBEGGS NAUGHTY NUBS vibrating

USER MANUAL



CONTROL:

1. **Power on/Change modes:** short press the "ON/OFF" button
2. **Power off:** hold the "ON/OFF" button

MAINTENANCE:

ATTENTION! After each use, do not forget to thoroughly clean the device; this will extend its lifespan.

We also recommend using a sex toy cleaner, which also helps remove microscopic dirt. Simply spray the product on, leave it on for about 1 minute, and then dry with a lint-free towel or cloth.

WATER RESISTANCE:

The product is fully **waterproof**.

LUBRICATION:

Use only **WATER-BASED** lubricants. Other lubricants (e.g. silicone) could irreversibly damage the surface of the device and make it sticky.

CHARGING:

The product is powered by a built-in, disposable, non-rechargeable battery.

STORAGE:

Store separately from other sex toys in a dry, cool and dark place out of the reach of children.

PACKAGE CONTENTS:

- 1× masturbator
- 1× removable, non-rechargeable vibration unit
- 1× user manual