

PUMP WITH VIBRATOR 2IN1 NS NOVELTIES INYA TRIPLE DELIGHT



User manual

CONTROL

- 1) To turn on, just hold the "power" button for two seconds, and to turn off the whole toy.
- 2) Each part of the gadget has a separate button.
- 3) To switch on the individual functions, just press the symbols briefly - the wave for the vibration, the three vertical lines for the vacuum pump and the button with two lines for the tongue.
- 4) Short presses of the individual buttons switch the programs of the parts.
- 5) To turn off only a specific part, hold the button for two seconds.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent.
You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **waterproof**, so maintenance is very easy.
It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.
Charging time is about 120 minutes.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a pump with a vibrator and a magnetic USB cable for charging.