



Perk

Online user manual

Arcwave Perk pleasures the prostate and perineum with powerful dual motors and adjustable inner arm for a comfortable, tailored fit. Heighten masturbation with new sensations and play using remote control.

Table of contents

1. Get to know your Perk

2. Start your Journey

3. Pair your toy

4. Cleaning Tips

5.

Charging Tips

6.

Battery change


7.

Safety Instructions

8.

General Information

1. Get to know your Perk



1

Prostate stimulator

2

Adjustable hinge

3

Magnetic charging pins

4

Turn ON / OFF
Change vibration pattern


5

Perineum stimulator

6


Arcwave remote

2. Start Your Journey



Before using your Perk please charge and clean your toy.

Perk is designed to be adjusted to fit you. You can make small adjustments to the position of Perk's internal perineum stimulator at the adjustability point indicated by the dot in the illustration.



Apply a water-based lubricant to the prostate stimulator and your anus. Slowly insert the stimulator, allowing the anal muscles time to relax and stretch without pain.



Turn on your device by holding the (A) button for second until the vibration and the LED activates. Perk is now ready to be used. You can cycle through the 10 different vibration patterns by pressing the (A) button. Turn off your device by holding the (A) button for 2 seconds. Keep control in the palm of your hand with Perks compact remote.




Increase or decrease the intensity of each vibration pattern by pressing the (+) or (-) button. To change your vibration pattern press (>) button to cycle to the next or press (<) button to go to the previous vibration pattern.



For removing Perk allow the anal muscles to relax and gently pull on the base.

3. Pair your toy



Perk comes paired to the remote out of the box. In case of a connection issue, hold the (A) button on Perk for 5 seconds. The LED will start flashing. Hold the (~) button on your Arcwave remote for another 5 seconds. Once paired, Perk will vibrate 3 times and the LED will stop flashing.

4. Cleaning Tips



Perk is IPX7 waterproof. This means it can be submerged in water without damage. We recommend using a premium toy cleaner for the best result. Dry it with a lint-free cloth.

5. Charging Tips



Enjoy 120 minutes of play with every charge. When it's time for a recharge, place the charger on the magnetic pins. After 90 minutes, your toy is ready to go.

- Charging: LED pulses
- Full: LED on
- Less than 25% battery, LED flashes for 4 seconds

6. Battery change



To change the battery in your remote control, simply pull off the bottom cap and lift out the battery.

Remove the cover and take out the battery.

Replace it with a non-rechargeable 4LR44 battery and reinstall the plastic cover.

7. Safety Instructions

WARNING

Sold as a novelty product only. Not suitable for medical purposes. Only use the product for the intended purpose. Keep out of reach of children. If you are under a physician's care and/or have a condition requiring the use of any medical device, please consult your physician before using this product. Stop using the product immediately if you experience any skin irritations, pain or discomfort and consult your physician.

This product can be used by adults only. Persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge may only use the product if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved. Children shall not play with the product. Cleaning and user maintenance shall not be done by children. Do not use on swollen or inflamed areas of skin.

Remove piercings or jewellery in the genital area before use. Always clean the product before and after use according to the instructions given in the manual. To avoid damage to the product, the product and its battery must not be exposed to temperatures above 45°C, be dismantled or mechanically or electrically damaged. Sharing sex toys may transmit sexual diseases. Do not share your sex toys with users other than your partner. Use protective measures with your partner if necessary. Do not use the toy if you detect any cracks or signs of degradation in the cover material.

Check the charging device and the product regularly for damage and do not use in any case of damage. Magnetic fields can influence mechanical and electronic components such as pacemakers. Do not use the product directly over a pacemaker. Contact your physician for more information. Keep cards with magnetic stripes (such as credit cards) away from the product, as they may be damaged by the product's magnet. If your product appears to be functioning abnormally, turn it off and consult the support section on our website.

Disinfect directly after each anal use. Failure to sufficiently lubricate may cause tearing of the delicate skin lining the anus. To prevent the transfer of bacteria, do not swap the product from the anus to the vagina without cleaning the toy with soap and water or toy cleaner first. Misuse of anal stimulators / prostate massagers may cause bruising, painful injury or, in rare cases, permanent damage to the anus. Do not use anal stimulators / prostate massagers under the influence of alcohol or drugs, since such use may impair the user's judgement and increase the risk of injury. Do not use desensitising sprays or creams prior to insertion, as this will prohibit your pain sensors from responding. Do not use

the device if you have a decreased sensation of pain in the area of the anus, since this could hinder your ability to detect possible injury.

Before use, consult your physician if you have any of the following health conditions: a blood clotting disorder, peripheral vascular disease, nerve disease, rectal bleeding, active Crohn's disease or active Ulcerative Colitis (UC) or similar diseases. If you experience any complications when using this device, discontinue use immediately and seek medical attention. If you have concerns regarding your health, don't be shy to consult your physician before using this device.

CHARGING

Before the first use of the charging device, check the local voltage level, since the local mains voltage may not exceed the maximum mains voltage given on the charging device. The product must only be charged at an appropriate, extra-low voltage corresponding to the marking on the product: 3.7V = 320mAh

Do not use or clean the product while the battery is charging. Never immerse the charging device or charging cable in water or other fluids. This product contains batteries that are nonreplaceable. This product contains a rechargeable Li-ion battery. Disconnect the charging cable from the electrical supply each time after the product has been charged. Do not disassemble, puncture, modify, drop, throw or cause other unnecessary shocks to the batteries.

Please ensure to properly insert the removable batteries into the designated slots of the electrical product following the indicated polarity markings for correct installation, discharged replaceable batteries must be removed from the unit and disposed of safely. If the device is to be stored without being used for a long time, replaceable batteries should be removed. Supply terminals are not to be short circuited. Do not charge non-rechargeable batteries. Do not put batteries in your mouth. If swallowed, contact your local physician immediately. Use only 4LR44 battery. Do not use batteries, or charge rechargeable batteries, that appear to be leaking, discoloured, rusty, deformed, emit an odour or are otherwise abnormal.

FOR OPTIMAL USE OF THE PRODUCT, PLEASE FOLLOW THE FOLLOWING GUIDELINES

To guarantee a long battery life, please charge the product regularly, even if not in use. Store in a secure, dry place without exposure to direct sunlight. We recommend using a water-based lubricant with your product. To prevent damage to the product, do not use perfumed, alcohol-based lubricants, gels or massage oils with the product. Do not use silicone-based lubricants with silicone products.

NOTE ON BATTERIES

European regulations require that we provide the following information:

Batteries and rechargeable batteries must not be disposed of in household waste. As an end user, you are legally required to return used batteries. Please use official collection facilities such as the collection points provided by public waste management authorities to do so. You can also return used batteries that we carry or have carried as new batteries to us. Please contact us at care@arcwave.com. To prevent short circuits, the poles of lithium batteries should be taped before returning. For safety reasons, we ask you not to send the batteries to us by mail and refer you to the regulations for sending hazardous goods provided by mail carriers. If the batteries are permanently installed in the product, please do not try to remove them yourself. This may cause permanent damage to the device. Your obligations as a customer are otherwise regulated by the WEEE Directive and the national implementation law. Please observe the information in the manual and the safety instructions to prevent waste and littering.

Used batteries contain harmful substances that can damage the environment or your health if they are not stored or disposed of properly. In particular, this applies to the improper handling of lithium batteries. Batteries also contain important raw materials such as iron, zinc, manganese and nickel and can be recycled. Separate collection allows these raw materials to be recycled and prevents negative impacts on the environment and human health from released pollutants.

The sign with the crossed-out waste bin means that you must not dispose of batteries and accumulators with household waste.



If the legal requirements are present, this sign means that the following symbols and their meaning must be used when labeling the batteries:

Hg: Battery contains more than 0.0005 percent mercury by mass

Pb: Battery contains more than 0.004 percent lead by mass

Cd: Battery contains more than 0.002 percent cadmium by mass

NOTES ON THE DISPOSAL OF ELECTRICAL EQUIPMENT

European regulations require that we provide the following information:

We would like to point out to owners of electrical equipment that old electrical equipment must be collected separately from municipal waste in accordance with applicable legal regulations. Batteries and accumulators that are not firmly encased in the old electrical equipment, as well as bulbs that can be removed from the equipment without being destroyed, must be separated from the old equipment in a non-destructive way before being given to a collection point for proper disposal. Please refer to the separate instructions for the disposal of batteries. The symbol of a crossed-out waste bin shown below and affixed to old electrical equipment also indicates that the equipment must be collected separately:



According to the WEEE Directive and the national implementation law, as distributors of electrical equipment, we are required to take back certain waste electrical equipment free of charge. When you purchase a new electrical and electronic device, you can surrender an old electrical device that essentially performs the same functions as the new device to us free of charge. If your old electrical equipment is not larger than 25 centimeters in any dimension, you can also surrender it to us free of charge without purchasing a new device. Please contact us at care@arcwave.com. We will then arrange the return of the old electrical equipment. For safety reasons, we would like to ask you to refrain from shipping lighting equipment (such as bulbs). Please use the collection points provided by public waste management authorities to return lighting equipment or contact us directly at the aforementioned e-mail address. You can also return old electrical equipment to any of the collection points run by the public waste disposal authorities. You are making an important contribution to the reuse, recycling and other recovery of old appliances by sending your old electrical equipment for separate collection in the proper collection groups. As the end user, you are responsible for deleting personal data from the used electrical equipment before handing it in for disposal. Please observe the information in the manual and safety instructions to prevent waste, and please check for possible repair options.

8. General Information

Model: Perk

Model No.: PRK2A

ELECTRICAL RATING

Electrical Rating:

3.7 V = 0.32 A: built-in li-ion rechargeable battery.

5 V = 0.5 A : When charged using USB charging device.

Use USB AC adapter (not included) with power output corresponding to product rating.

FCC SDoC (Arcwave , PRK2A):

Responsible party - U.S.

Contact Information: WOW Tech USA Ltd. 103 Foulk Rd, Ste. 202 Wilmington, DE, USA 19803-3742

Attention: President

FCC and IC statements: This device complies with Part 15 of the FCC Rules and Industry Canada license exempt RSS Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003. Cet appareil est conforme à la partie 15 des Règles FCC et aux normes RSS exemptes de licence d'Industry Canada. L'utilisation est soumise aux deux conditions suivantes : (1) Cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles qui pourraient provoquer un fonctionnement non souhaité. Cet appareil numérique de classe B est conforme à la norme canadienne NMB-003.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device must not be co-located or operating in conjunction with any other antenna or transmitter. The device has been evaluated to meet general rf exposure requirement. The device can be used in portable exposure condition without restriction. The device is compliance with rf field strength limits, users can obtain canadian information on rf exposure and compliance. Le présent appareil est conforme de ce matériel aux conformités ou aux limites d'intensité de champ rf, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité d'acquérir les informations correspondante.

For EU only:

Operation Frequency (MHz): 2402 - 2480

Max. RF output power (dBm), device: -1.44

Max. RF output power (dBm), remote: -11.28

MANUFACTURER WARRANTY

WOW Tech Europe GmbH offers a voluntary manufacturer warranty for this product which applies in addition to the statutory warranty to which consumers are entitled to towards their seller. Details about the manufacturer warranty can be found on the website www.arcwave.com.

CUSTOMER CARE

For further information please visit our website care@arcwave.com or www.arcwave.com.

MANUFACTURED AND SOLD BY WOW TECH EUROPE GMBH

Hermann-Blankenstein-Straße 5 - 10249 Berlin, Germany

Lovehoney Ltd 100 Locksbrook Road - Bath BA1 3EN

Designed in Germany. Date of issue: 01/2025. MA-00377 rev C