

RS ESSENTIALS FIRST VIBE KIT (Vibrator)

User manual

CONTROL

- 1) Unscrew the cap of the vibrator and insert the batteries according to the poles.
- 2) After screwing in, briefly press the button on the base. The vibrator will start its first vibration.
- 3) Additional short presses of the button change the individual vibration and pulsation rhythms.
- 4) To turn the vibrator off, hold the button for 3 seconds.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **water resistant**, so maintenance is very easy. Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!** You could only immerse the product in water if it was **waterproof**.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by two AAA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.