

VIBRATING BALLS WITH CLITORAL STIMULATOR Y.LOVE SARA



User manual

CONTROL

- 1) Hold the power button on the egg for 2 seconds. It will greet you by lighting the LED and going into standby mode.
- 2) Subsequent short presses of the button turn on and change the individual rhythms of vibration and pulsation.
- 3) Turn it off by long pressing the power button again for 2 seconds.
- 4) For use with the remote control, place the balls in standby mode.
- 5) Hold the power button on the remote to turn it on.
- 6) Short press the middle button to turn on and change the vibration of the balls, short press the top button to turn on and change the vibration of the remote.
- 7) Hold down the corresponding button on the controller for 2 seconds to pause the vibration.
- 8) You must then turn off the balls and the controller by holding down its own power button for 2 seconds.

MAINTENANCE

After each use, rinse the balls with lukewarm water and soapy detergent. You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The balls are **water resistant**, so maintenance is very easy. Splashing water may fall on the balls, **but you MUST NOT immerse them in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The balls is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or The remote is also powered by an integrated battery, which you charge with the same cable as the balls.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find vibrating balls, remote control and USB cable for charging.