

ANAL PLUG Y.LOVE ABBOT

User manual



CONTROL

- 1) Hold the bottom power button on the base for 2 seconds. The vibrator will greet you by lighting up the LED.
- 2) Subsequent short presses of the top button start individual rhythms of vibrations and pulsations and move them forward, short presses of the bottom power button move back one level.
- 3) To turn the pin off, long press the power button again for 2 seconds.

MAINTENANCE

After each use, rinse the anal plug with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The anal plug is **water resistant**, so maintenance is very easy. The anal plug can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The anal plug is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find an anal plug and a USB cable for charging.