REBEL MEANS GEAR MASTURBATOR



User manual

CONTROL
1) Turn on the masturbator using the “ON/OFF” button.
2) Press this button repeatedly to change the individual vibration programs.
3) The button with the “flame” symbol is used to preheat the masturbator to a temperature of 40°C.
4) The button with the “arrow” symbols is used to adjust the speed of the up/down movements.
5) Turn off the masturbator using the “ON/OFF” button.

MAINTENANCE
We also recommend using an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.
The masturbator is not waterproof or water-resistant, so we DO NOT RECOMMEND using water for maintenance.

WATERPROOF
The product is **not water resistant or waterproof!**

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The product is powered by an integrated battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.
Charging time is about 90 minutes.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
In the package you will find a masturbator and USB cable for charging.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169