

VAGINAL TRAINER SWAN MINI CLUTCH

User manual



CONTROL

- 1) Hold both buttons on the handling loop for 5 seconds to turn it on.
- 2) It greets you with two short vibrations and starts the training mode.
- 3) Press the soft backlit spot to turn on the vibration.
- 4) Press the egg, set the desired vibration intensity and press the button with the lock symbol at the same time.
- 5) This way the vibration will stay according to your setting.
- 6) Another short press of this button will bring you back.
- 7) Short presses of the button on the opposite side without the symbol will switch on and change the individual vibration and pulsation rhythms.
- 8) To turn the trainer off, hold both buttons again for 5 seconds.

MAINTENANCE

After each use, rinse the trainer with lukewarm water and soapy detergent.

You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The trainer is water resistant, so its maintenance is very simple.

The stimulator can be splashed with water, but you **MUST NOT** immerse it in water!

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The trainer is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vaginal trainer, magnetic USB cable for charging and a velvet bag for storing gadgets.